


# NORSAP 1800 ACTIVE




The NorSap 1800 Active platform provides numerous options and configurations, ensuring full adjustability. This modular platform has been specially designed for optimal customer component integration in a way that ensures long-term operation and easy servicing. The Active series has a fully gas-spring actuated ergonomic system with six step-less adjustment features, ensuring optimal working positions for the user.



## NORSAP 1800 ACTIVE M


**8840** Fixed flat oval column. Starting from 53 to 88



**8820** Aluminium back. Flat oval column 63/73

**8810** Aluminium back. Flat oval column 67/80

**8800** Aluminium back. Flat oval column 72/92



## NORSAP 1800 ACTIVE L

**8860** Fixed XL column. Heights 70 with footrest

**8865** Fixed XL column. Heights 45 without footrest



The NorSap 1800 ACTIVE is a highly profitable chair in terms of options and adjustability. The modular design provides optimal customer component integration in a way that ensures long-term operation and easy servicing. Spacious armrest with room for internal cabling makes it easy to install most equipment and accessories. A fully gas spring driven ergonomic system comes standard with up to 6 step-less adjustments. NorSap 1800 Active is a cost-efficient chair for a vast ergonomic spectre.

The series fully complies with the strict ergonomic requirements found in the NORSOK regulations. Our chairs are designed to comfortably fit 90 % of all users according to the ISO7250 Standard.

All sitting heights measured without load - a variation of 2-5 cm may occur depending on the load due to contraction of gas-struts, springs and upholstery. The undercarriage of the seat allows variation of height adjustment. All fixed height columns can be cut to desired sitting height within minimum and maximum specification.